



CABINET PARTS

REFRIGERATOR

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT2255706	Use & Care Guide	15		Hinge Cover, FC	28	2186443	Housing, Water Filter
	LIT2255384	Service & Wiring Sheet		2203407W	White	31	489500	Screw
	LIT2261497	Energy Guide		2203407T	Biscuit	35	489464	Screw
	LIT628370	Modular Icemaker Service Sheet		2203407B	Black	41	940139	Drain Fitting
2	2174748	Front Roller (2)	16	2217075	Hinge Bottom (2)	42	1108438	Extension Tube
3	3400517	Screw	17	3400103	Screw	43	1108439	Clip, Drain Tube
4	2196236	Roller (Rear) (2)	21		Filler, Wrapper	47	2188739	Cover, Unit
5	489427	Screw		2196094	White	48		Cabinet (Not A Serviceable Part)
6	2155013	Clip, Grille		2196150	Biscuit	49		Hinge Cover, RC
7	489478	Screw	22		Grille		2203408W	White
8	2203098	Plate, Screw		2186881W	White		2203408T	Biscuit
9	2156056	Shim		2186881B	Black		2203408B	Black
10	3400113	Screw	23	489497	Screw	52	549193	Clamp, Service Cord
11	8281227	Screw	25	2203220	Water Filter	53	489084	Screw
12	2203770	Hinge Top, FC	27		Cap, Water Filter	54	2155311	Door Closer, Lower Cam (2)
13	2203771	Hinge Top, RC		2186494W	White	55	489483	Screw
14	8281149	Screw		2186494T	Biscuit			
				2186494B	Black			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide, Meat Pan Control
4	2182147	Louver
5	2256035	Bracket, Dual Crisper Lights
7	2256037	Wire Harness, Dual Crisper Lights
11	489290	Screw (2)
13	2206273	Shelf Ladder
14	487539	Screw
15	2179404	Rack, Wine & Egg
22	1123919	Bracket Retainer
24	2209753	Air Diffuser Assembly
25	2152019	Air Diffuser Cover
26	2150331	Cover, Conduit
27	486298	Screw
29	2162085	Socket
31	2217199	Reservoir
33	527949	Light Bulb
34	2209769	Light Lens
37	488280	Screw (2)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------


(White) (Biscuit) (Black) (Stain)

Illus. No.	Part No.
1	22
2	22
3	22
4	21
5	21
6	21
7	21
8	22
9	21
10	21
11	21
12	21
13	21
14	21
15	22
16	21
17	34
18	21
19	21
20	82

8198769

FREEZER LINER PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS


For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
3	2171713	Door, Ice Compartment
4	940014	Hole Plug
5	2223539	Basket, Freezer Square
6	842534	Clip, Air Duct (2)
7	2196206	Support, Stud (4)
8	2171766	Front, Basket
10	2176134	Grommet
11	2223535	Basket, Sloped
17		Slide, Basket
	2261148	Right Side
	2261149	Left Side
18	486298	Screw
19	1115373	Switch, Rocker Arm
20	8281158	Screw
21	2196483	Stud Assembly
23	2171714	Shelf, Top Compartment
24	2171705	Light Lens
25	527949	Light Bulb
26	2162085	Light Socket
27	2196207	Stud, Rear
28		Slide, Container
	1119237	Left Side
	1119293	Right Side
29	489100	Screw
30	3400893	Screw
31	2174267	Shelf (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS


For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2183726	Bracket, Motor
2	2188385	Motor, Dispenser
3	2152713	Solenoid Assembly
4	2149100	Guide, Solenoid
6	1115374	Clip, Wiring
7	2206501	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	2205716	Coupling, Motor
10	489478	Screw
11	2162085	Socket, Light
14	2196091	Ice Container
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	2196295	Auger
28	2209781	Drum
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2155231	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
37	2180348	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
44	2204321	Front Cover, Ice Container
45	527949	Light Bulb
46	2171706	Light Lens, Dispenser

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #7)
	2207327W	White
	2207327T	Biscuit
	2207327B	Black
	2207327S	Stainless Steel
3	2218122	Door, Compartment
4	2193409	Holder, Beverage
6		Insert, Handle
	2173825	White
	2186863T	Biscuit
	2173829	Black
7		Door Gasket
		Magnetic
	2221302	Mist Beige
	2221313	Black
8		End Cap, Handle
	2194778W	White
	2194778T	Biscuit
	2194778B	Black
9	3400852	Screw
10		Retainer, Insert
	2194777W	White
	2194777T	Biscuit
	2194777B	Black
11	489491	Screw
12	2182178	Door Closer, Upper Cam
13	2159124	Gasket
14	489420	Screw
15		Bracket, Door Stop
	2206629	Bright Zinc
	2206629B	Black
16	2171063	Shelf Bin (4)
17	3400012	Screw
18	2182180	Thimble-Top

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item 8 And Dispenser Front Parts)
	2216263W	White
	2216263T	Biscuit
	2216263B	Black
	2216263S	Stainless Steel
2		Retainer, Insert
	2194777W	White
	2194777T	Biscuit
	2194777B	Black
3		End Cap (2)
	2194778W	White
	2194778T	Biscuit
	2194778B	Black
4	489491	Screw
5	3400012	Screw
6	3400852	Screw
7	2171070	Shelf Bin (4)
8		Door Gasket, Magnetic
	2221303	Mist Beige
	2221314	Black
9		Insert, Handle
	2173825	White
	2186863T	Biscuit
	2173829	Black
10	2209681	Trim, Door Shelf
12	488500	Screw
13	2200400	Wire Harness
14	2182179	Door Closer, Upper Cam
15	2154473	Connector
16	489420	Screw
17	2206629	Bracket, Door Stop
18	2182181	Thimble-Top

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)

(Stainless Steel)



DISPENSER FRONT PARTS


For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2256199	Spring, Torsion
5	2196195	Pin
6	2180352	Door, Ice
7	2206423	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206670W	White
	2206670T	Biscuit
	2206670B	Black
10	2209718	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2180259	White
	2186850	Biscuit
	2180261	Black
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch (2)
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2180268	White
	2186852	Biscuit
	2180270	Black
18		Switch Assembly (Not Available— Order #23)
19		Overlay, Front Cover (Not Available— Order #23)
20	2187409	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2220096W	White
	2220096T	Biscuit
	2220096B	Black
25	2195051	Strain Relief

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	486692	Speed Nut
2	2190685	Fan, Blade
3	2204484	Condenser Assembly
4	489464	Screw
5	2208280	Clip, Wire
6	8281160	Screw
8	2161302	Sleeve
9	2216997	Insert, Bracket
10	2255798	Tube, Condenser to Heat Loop
11	2216914	Clip, Condenser
12	4387731	Cover (Service Compressor Only)
13	2154697	Overload (Service Only)
14	2205765	Tube Suction
15	2183454	Relay (Service Only)
16	2220475	Start Device, Combination (Start Relay and Overload) For Production Compressor Only
17	999532	Capacitor Production
	1118576	Service
18	4387765	Wire, Capacitor (Service Only)
19	2223314	Clip, Retaining
21	489478	Screw
22	2209611	Evaporator
23	2161324	Clamp
24	2206005	Fan, Motor
25	1105523	Tray, Evaporator
26	2256150	Heat Shield

Illus. No.	Part No.	DESCRIPTION
27		Drier
	2199167	Production
	4387019	Service
28	2212192	Compressor (Includes Items 12, 13, 15, 17, 18, 27 & 38) (Also Order 876765 Tube Kit)
30	2157397	Unit Mounting Frame
31	2187783	Unit, Harness (Includes Power Cord)
32	2181929	Fan, Motor Bracket
33	2188175	Heater, Defrost
34	2161330	Clip
35	2196155	Bi-Metal, Defrost
37	489373	Screw
39		Grommet (4)
	1100826	Production
	4387558	Service
40	489340	Screw
41	2196202	Air Baffle
42	2155547	Clip, Heat Shield
43	2206281	Unit Cover, Bottom
44	489396	Clip
48	1127911	Unit Mounting Rail
49	8281232	Screw
50	2186495	Guard, Fan
52	2172840	Strap
53	489427	Screw
55	488649	Screw
63	2209709	Connector, Water Tube

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

REFRIGERANT CHARGE


5.00 oz.
(R-134A)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2161231	Air Scoop
5	2203593	Air Duct Freezer
7	2149299	Fan Motor
8	2169142	Fan Blade
10	2176759	Fan Grommet (2)
11	2182146	Duct, Icemaker
12	2206504	Harness, Fan Evaporator, And Heater, Bi-Metal
13	2155789	Gasket Cover
14	2172840	Wire Tie
16	2203876	Gasket
17	2203841	Cover, Evaporator
18	489355	Screw
21	489478	Screw
22	2203595	Support, R.S
23	2203596	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8201785	Control Box
2	2196001	Tube Barrier, Thermostat
3	489214	Screw (3)
4	2149705	Light Switch
5	2161282	Thermostat
6	2252148	Electronic Control
7	489398	Screw (2)
9	627068	Screw
10	2181741	Slide, Air Control
11	2172906	Grommet, Light Bar


Illus. No.	Part No.	DESCRIPTION
12	2161466	Slide, Thermostat
13	489084	Screw (2)
14	2179920	Light Bar (RC)
15	2161306	Pivot Arm
16	489290	Screw (2)
17	2162085	Light Socket
18	2172931	Heat Shield
19	527949	Light Bulb
20	2212237	Control Box Harness
21	1115374	Clip, Wiring

Illus. No.	Part No.	DESCRIPTION
22	1115375	Clip, Wiring
23	2161308	Connecting Rod
24	489391	Fastener, Push-On
25	2211959	Escutcheon, Control Box
26	2179921	Light Bar (FC)
27	2175513	Window
28	2213462	Harness, Indicator Light
29	489203	Spring Washer
30	2161307	Connecting Rod (Short)
31	2200096	Cover, Light Lens

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2209774	Chute, Water
3	2255012	Tube, Filter Outlet
4	2188744	Tube, Filter Inlet
5	628379	Clip, Fuse
7	2223137	Tube, Water
9	489478	Screw
10	2188746	Valve, Solenoid
14	2208136	Tube Clip
18	2174155	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	627843	Ejector
24	2182124	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	489322	Screw
30	489276	Screw
31	2209675	Shut Off Arm
33	628320	Bracket
35	626653	Module Assembly (Includes Items 37 & 38)
36	488208	Screw
37	627811	Motor
38	489136	Screw
100	4317943	Complete Icemaker Assembly

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PARTS NOT ILLUSTRATED

For Models: KSRD25FKWH14, KSRD25FKBT14, KSRD25FKBL14, KSRD25FKSS14
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)			Miscellaneous			Refinishing Material		
Customer Touch-Up Material			212643		Sealer, Gum (4 Feet)	799340		Enamel, Black (1 Qt. Uncut)
*350942		Primer, White (13 Oz. Spray Can)	479502		Tape, Vinyl (3/4 x 108")	799344		Enamel, White (1 Qt. Uncut)
*350939		Enamel, Black (13 Oz. Spray Can)	876370		Kit, Insulation (2 Pcs. x 3" x 24" X 48")	4392900		Enamel, Biscuit (1 Qt. Uncut)
*350930		Enamel, White (13 Oz. Spray Can)	876305		Kit, Insulation (14 Pcs. x 3" x 24" x 48")	TORX SCREW WRENCH		
*4392901		Enamel, Biscuit (13 Oz. Spray Can)	978941		Insulation, Fiberglass (63-1/2" x 35-1/2" X 2-5/8)	1117510		Torx Key
72017		Brush Touch-Up Kit (White)	876029		Kit, Foam Slab (30" x 32-1/2" x 1-1/2")			
4392899		Brush Touch-Up Kit (Biscuit)	505587		Sealer, Mastic (1 Qt.)			
72032		Brush Touch-up Kit (Black)	503695		Cork, Sealer (1/4 Pound)			
*Important: The spray paint is not to be used where the paint may make contact with the door gaskets.			511873		Touch-Up, White Porcelain (2 Oz.)			
			542638		Grease, Silicone (1/2 Oz.)			
			542639		Cement, Alumilastic (1-1/4 Oz.)			
			606755		Bag, Insulation (36-5/8" x 46")			
			799833		Kit, Evaporator Repair (Aluminum Epoxy)			
			833938		Kit, Terminal Connector			
			2209780		Ice Container Assembly			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST